

## **GB** Time zone setting / Manually fixing to -1h UTC

If this weather station shall be used in an area where the UTC time standard is used (e.g. parts of the UK and Portugal), the time zone can be fixed manually to -1h UTC. To do this, follow the next steps.

Setting sequence:

Year > Month > Day > **Time zone** > 12/24-hour mode > Hours > Minutes

1. Press and hold SET button for approx. 2 seconds to change to time setting mode.
2. Year digits flashing.
3. Press SET button to continue to the next setting.
4. Month digits flashing.
5. Press SET button to continue to the next setting.
6. Day digits flashing.
7. Press SET button to continue to the next setting.
8. **Time zone digits** flashing.
9. Press DOWN button to change the value to **-1**.
10. Press SET button to confirm and continue to the next setting.
11. 12/24-hour digits flashing.
12. Press SET button to continue to the next setting.
14. Hours digits flashing.
15. Press SET button to continue to the next setting.
16. Minutes digits flashing.
17. Finally press the SET button to save the settings and exit the setting mode.



## **PT** Definição do fuso horário/Ajuste manual para -1h UTC

Se esta estação climática for utilizada numa área em que seja utilizada a norma horária UTC (por exemplo, partes do RU e Portugal), o fuso horário tem de ser ajustado manualmente para -1h UTC. Para tal, siga os seguintes passos.

Sequência de definição:

Ano > Mês > Dia > **Fuso horário** > Modo 12/24 horas > Horas > Minutos

1. Mantenha premida a tecla SET durante cerca de 2 segundos para alterar o modo de definição da hora.
2. Os dígitos de ano piscam.
3. Prima SET para avançar para a próxima definição.
4. Os dígitos de mês piscam.
5. Prima SET para avançar para a próxima definição.
6. Os dígitos de dia piscam.
7. Prima SET para avançar para a próxima definição.
8. Os **dígitos do fuso horário** piscam.
9. Prima a tecla para BAIXO para alterar o valor para **-1**.
10. Prima a tecla SET para confirmar e avançar para a próxima definição.
11. Os dígitos de 12/24 horas piscam.
12. Prima SET para avançar para a próxima definição.
14. Os dígitos de horas piscam.
15. Prima SET para avançar para a próxima definição.
16. Os dígitos de minutos piscam.
17. Por último, prima a tecla SET para guardar as definições e sair do modo de definição.